

Check It™ User Notes

WHAT DOES IT DO?

Check It makes sure the telephone line that connects your scheme to the control centre is working. Every so often the control centre will make a test call. **Check It** stops this test call reaching your scheme, and then makes a reply call back to the control centre. If the control centre does not receive this reply the control centre operators see a warning to say there may be a problem with the line. The operators will first try to call the scheme to speak to someone. If they speak to you they may ask you to raise a test alarm once their call to you has ended.

Although **Check it** looks like a Tunstall Lifeline phone it is very different inside. It is not designed to raise alarm calls and is completely silent. If it is disconnected or removed the monitoring centre operators will receive warnings saying the telephone line is faulty.



LINE DISCONNECTED

Every time **Check it** receives a test call and then makes a test call in reply, it briefly disconnects the scheme from the telephone network. Even if an alarm call is raised at exactly the same time do not worry as the system will automatically make a second attempt to dial the monitoring centre.

MAINS FAIL

If there is a power failure **Check It** will keep working using its back-up battery. If the power is not restored for 12 hours or more, and the back-up battery is exhausted, the **Check It** will stop working. However, if this happens it will still leave your scheme connected to the telephone network.

This system relies on features available from your telecoms network provider. In the event their service changes this may have a direct impact on the operation of this system.

All the reassurance you need

Tunstall

All the reassurance you need

Tunstall



03RTTE009A

**DECLARATION OF CONFORMITY WITH THE REQUIREMENTS
OF THE RTTE DIRECTIVE 1999/5/EC**

EQUIPMENT : Lifeline 4000 'Check It'
Model Number: 36200/408

EMC STANDARDS : EN 55022: 1998
EN 55024: 1998
EN 50130-4: 1995

SAFETY STANDARDS : EN 60950: 1992 inc. amendments 1,2,3,4 and 11

ASSOCIATED DOCUMENTS : Summary Information 03RTTE010A

The equipment identified above conforms to the essential requirements of the RTTE Directive 1999/5/EC. *The essential radio test suites have also been carried out.*

Signed

Date

6th August 2003

Position

Technical Director

The CE mark was first applied in 2003

Tunstall Telecom Limited, Whitley Lodge, Whitley Bridge, Yorkshire DN14 0HR

Telephone: 01977 661234 Facsimile: 01977 660562

Internet: www.tunstallgroup.com